



X5105 System configuration table

After updating the firmware, must refer to the X5105 system configuration table to re-setting all parameters.

Steps:

1. After updating the firmware, enter the item 21 【Reset ALL】 of the system menu , reset system parameter settings.
2. After reset, please according to the X5105 serial number to find to the corresponding configuration parameters.

【 一 】

Applicable serial number	X0300001~X0300150
	0300001~0300220

	Menu item	Function	setting
04	Tx AF Gain SSB	SSB mode: MIC Gain	60%
05	Tx AF Gain AM	AM mode: MIC Gain	50%
08	RX AF Gain AM	AM mode: Receive audio Gain	90%
09	RX AF Gain NFM	NFM mode: Receive audio Gain	90%
14	Misc Option	Digital baseband configuration	0x7A5C3360
20	Ext MIC Bias	External MIC Bias Setting	Enable

【 二 】

Applicable serial number	X0300151.....
	0300221.....

	Menu item	Function	setting
04	Tx AF Gain SSB	SSB mode: MIC Gain	80%
05	Tx AF Gain AM	AM mode: MIC Gain	50%
08	RX AF Gain AM	AM mode: Receive audio Gain	90%
09	RX AF Gain NFM	NFM mode: Receive audio Gain	90%
14	Misc Option	Digital baseband configuration	0x59A03360
20	Ext MIC Bias	External MIC Bias Setting	Enable

NOTE:

- 1.After operating, Save Settings, Exit system menu, power off and on again.
- 2.First use it, please check SQL、NR、NTH.
- 3.First use the Preset messages, please delete all garbled symbols in RE1 ~ RE3