
X5105_FW_V1_0_06_build001_alpha08 update instructions

Firmware update instructions

1. Optimizing the S table display.
2. Adding the new iambic-B mode
3. Adding the CW Keyer DI/DA Ratio
4. Optimizing the automatic key control logic.
5. Reconfigure the gain distribution of X5105 system.
6. adding four new system menu items .
7. Adjusted the system initialization operation method, it only need to operate a system reset after the update is complete.

New added system menus as follows:

Item 3 CW Keyer Iambic Mode

Item 4 CW Keyer DI/DA Ratio

Item 25 S-Meter Offset

Item 26 S-Meter Gain

Precautions:

1. After successful loading, enter the system menu and perform the reset operation;
2. After completing the reset, calibrate the S table as shown below:

For the S-table calibration method, please refer to the document "X5105 New Firmware S-Table Calibration Method 03-CZ180902".