

Important_X5105 host configuration instructions

After updating the firmware of the "X5105_FW_V1_0_03_build027.xgf" version, follow the instructions below to configure the system menu parameters.

The new firmware makes a structural adjustment for the digital baseband section. In order to adapt to the host device of each serial number, please configure your host according to the following settings.

Special Note

The parameter settings described in this document apply only to the X5105 host of the following sequence number:

- 1、X0300001~X0300150
- 2、0300001~0300220

Configuration instructions:

1. Press and hold "MENU" button, enter the system menu.
2. Enter the fourth menu [Tx AF Gain SSB], set to 20%.
3. Enter the 14th menu [Misc Option], set to 0x7A5C3360.
4. Enter the 20th menu [Ext MIC Bias], set to Enable.
5. Click Save and then exit the System menu.
6. Turn off X5105, than turn it on.

Finish.